

WATER DISPENSERS


Model:
V208 F



VERY IMPORTANT!
PLEASE READ CAREFULLY BEFORE USE

USER MANUAL

1. PARTS NAME



PARTS NAME LIST

1. Water guard
2. Heating lamp (red)
3. Warm lamp (green)
4. Natural tap (blue)
5. Hot tap (red)
6. Drip tray
7. Cabinet (for some models)
8. Air entrance
9. Hot switch (red)
10. Timer
11. Drain stopple
12. Power cord sets

2. IMPORTANT


1. Do not insert the plug into socket before the water comes out of the red (hot) tap.
2. Make sure the adoption of the earth wire with Three Pin-hole Socket and the Electric Leakage Protector is available to avoid any electric shock.
3. Pull out the power plug and drain out the water from drain stopple when the machine is disengaged for a long time.

3. FEATURES

1. It supplies hot and warm temperature water to meet the demands of people for drinking coffee or tea and having instant food or milk, drink, etc. It is suitable for households, hotels, offices and schools, etc.
2. Two, three or five gallon bottles pure water or RO-Purified water can be used as the water source.
3. Exact temperature control tech. are adopted. It is non-pollution and low noise.
4. The heating tank is made of food grade stainless steel. They are, safe and sanitary.

4. PLACEMENT

1. The unit should be placed flatly.
2. It is necessary to place the dispenser in cool shade, keep it away from direct sunlight and maintain its distance more than 15cm from the wall. There will be a distance of 15cm in the left and right side.
3. It is recommended to put this machine away from the furnitures and other appliances to avoid unexpected damage by water.
4. After the above mentioned steps then put the switches at off side.
5. To avoid a hazard due to instability of the appliance, it must be fixed in accordance with the instructions.
6. In the back of water dispenser there is a fixing sheet, consumers should connect the fixing sheet with the wall or unmoved object by themselves, in order to avoid it fall down.
7. **WARNING** - Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
8. **WARNING** - Do not use flammable appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.



5. OPERATION

1. Clean off the label on the cap of the bottle.
2. Insert the bottle vertically into the water guard and press the faps until the water flows out from the RED (hot) tap.
3. Insert the power plug into the socket, then turn on the switches (DONT TURN ON THE SWITCHES AT THE SAME TIME) to start the machine, the heating lamp light up. It need not your care, it can work automatically and provide water for you anytime. It will stop or start to work when the water temperature reach different setting values.

6. ATTENTION

1. Danger: Do not pull the power wire constrainedly. Do not pull or put the plug to start or stop the machine. Do not change the power cord set random.
2. Do not clean the machine with water to avoid unexpected electric shock. You should clean it by soft cloth.
3. Adopt the proper wire and socket to avoid wire overheating. Meanwhile, adopt the earth wire and the electric leakage protector to avoid any electric shock.
4. Children are forbidden to push or pull the hot (red) water tap.
5. Give this machine a dry, clean and shade place.
6. Do not move it roughly. Do not incline it over 45.
7. The air entrance can not be blocked by others. And you must change the disinfection net in the air device after a few months use.
8. The air entrance of the refrigerator which on the back plate can not be blocked, otherwise. The refrigerator will be damaged.
9. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
10. The product is for household use only.
11. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
12. Children should be supervised to ensure that they do not play with the appliance.

7. HOW TO CLEAN YOUR MACHINE

1. When you first use, please switch off the machine and pull out the bottle then drain out the water from drain stopples (BE CAREFUL OF THE HOT WATER) after 30 minutes running. Then put back the bottle and open the hot tap until water comes out.
2. If you use mineral water, it is necessary to clean the heating coil and tank with 2% cooking citric acid and clean water once a month to assure good performance and good water quality. The clean method is same to the above mentioned in clause 1. (Please note: You should clean again or more by pure water after drain out the citric water.)

8.TROUBLESHOOTING

Trouble	Causes	Remedy
No water from the faucets	Air entrance has been blocked	Take down the bottle and reassemble it
Do not provide hot or cold water	1. Too much water has been used in a short time 2. Electric connection is loose	1. Wait for a while and try again. 2. Make sure the switch is ON and the plug is in the socket.
Electrical leakage	The connection is not good	Make sure the earth wire and the leakage protector are available
Loud noise	Incorrect placement	Replace it away from other objects
Water leakage	The bottle is broken	Change a good one

CAUTION: In order to avoid a hazard due to inadvertent resetting of the thermal cutout, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

9.CORRECT DISPOSAL OF THIS PRODUCT



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Important statements : We checked up on above information carefully, any printing error or content misunderstanding, the manufacturer reserves the right of final interpretation. Please be noted that any technological improvements are subject to change without prior notice.